


OPERATING INSTRUCTIONS - You will need 4 x AA Batteries (not included)

Congratulation on your purchase of this quality "Smartlite® " Wall Clock. Your clock incorporates an innovative new technology called "SMARTLITE® " This enables the dial to stay illuminated in dark conditions or when the sensor is covered. The Smartlite® Sensor also automatically turns OFF the dial illumination in bright conditions to prolong battery life.

1) Turn the Hand set Knob Anti-clockwise to set the time (making sure the hands move clockwise only).

2) Now insert 1 X AA Battery (not included) into the "**clock section**" battery compartment, according to the diagram shown.

3) Now insert 3 X AA Battery (not included) into the **Smartlite®** battery compartments according to the diagram shown.



4) Smartlite® Switch

Slide the Smartlite® switch to the "AUTO" position to turn "ON" the "Smartlite® " feature. The clock will now gently light up in a dark environment or when the Sensor is covered.

Smartlite® Sensor
Automatically turns OFF light during the day.

Note: We Recommend that the Batteries are replace once a year. If the Green Smartlight® feature becomes weak please **replace the batteries.**

→ **Battery compartment for Smartlite® Feature**

If you have any queries, problems or do not understand any part of these instructions, please Contact us on the Help line given at the top of the page.