


Quartz Clock Operating Instructions



1. Insert 1 X (AA) battery as the indication in the battery holder; the movement will be damaged if the battery is not properly inserted as instructions.
2. Set the time by turning the knob.
3. Replace the battery once a year even if the clock is still running.
4. Remove battery when clock is not in use.

Battery not included